


HT Gear Drive Maintenance Manual Case Sizes 1,2,3



Equipment Reference:

For Service and
Information Contact

TABLE OF CONTENTS

Case Sizes 1,2,3

	Page
Maintenance Introduction	1
<hr/>	
Disassembly	2
<hr/>	
Gear Drive 2	
Spiral Bevel Pinion Cartridge	4
Output Shaft	5
Upper Bearing Cap	6
Input Shaft	7
Input Shaft Bearing Cap	8
Assembly	9
<hr/>	
Input Shaft	12
Upper Bearing Cap	13
Output Shaft	14
Spiral Bevel Pinion Cartridge	15
Gear Drive	18
Gear Drive Item List (Parts)	25
<hr/>	
Supplemental Information	
<hr/>	

TABLE OF CONTENTS

Case Sizes 1,2,3

	Page
<hr/>	
Tables	
<hr/>	
Table 1: Bolt Tightening Torque	10
Table 2: Backlash Setting	20
Figures	
<hr/>	
Figure 1: Spiral Bevel Pinion Cartridge Assembly	4
Figure 2: Output Shaft Assembly	5
Figure 3: Upper Bearing Cap Assembly	6
Figure 4: Input Shaft Assembly	7
Figure 5: Input Shaft Bearing Cap	8
Figure 6: Sequential Tightening	11
Figure 7: Input Shaft Assembly	12
Figure 8: Upper Bearing Cap Assembly	13
Figure 9: Output Shaft Assembly	14
Figure 10: Spiral Bevel Pinion Cartridge Assembly	15
Figure 11: Torque Reading	16
Figure 12: Cartridge Measurement	17
Figure 13: Shim Calculation	18
Figure 14: Backlash Setting	20
Figure 15: HT Gear Drive: Size 1	24

MAINTENANCE GEAR DRIVE

Case Sizes 1,2,3

This manual contains instructions for HT gear drive disassembly and assembly. Refer to the agitator manual for all other information relative to the agitator.

Other than periodic lubrication as defined in the *Lubrication* section of the Agitator Manual, no routine operational gear drive maintenance is required.

To assure the longest life from your gear drive, annual shutdowns which can correspond with plant shutdowns should be planned. Gear tooth wear patterns, shaft/bearing end play, alignment, bolting and the condition of all seals should be checked. Worn parts should be replaced and any areas of general concern should be brought to the attention of your *local Chemineer office*.

GEAR DRIVE

Case Sizes 1,2,3

Disassembly

Gear Drive (Figure 15, page 24)

1. Remove change gear cover [276] and gasket [277].
2. Remove pinion locknut [217] and change pinion washer [216].
3. Remove change pinion [215]. All change pinions are spline mounted.
4. If the gear drive is equipped with a low speed oil wiper, remove slinger trough [332]. See the *Supplemental Information* section of this manual.
5. Loosen change gear bolt [218] two turns. Apply a gear puller to disengage the taper. Remove the gear puller and remove change gear bolt [218], lockwasher [219] and change gear washer [220]. All change gears are taper hub mounted.

CAUTION! Release of taper fit can cause the change gear to jump off the shaft if not retained.

6. Remove change gear and key [221, 222].
7. Remove spiral bevel pinion cartridge assembly [223] (Figure 1, page 4) and shim set [236]. Keep the shim set intact for reference at assembly.
8. Remove input shaft cap cover, V-ring, gaskets, and bearing cap [202, 203, 204, 205].
9. Loosen the (3) setscrews in locknut [208] two turns. Remove the locknut.
10. Press input shaft [212] out of bearing [210] cone through the change gear end of the housing. Proceed slowly when removing the input shaft through the housing to avoid damage to the input shaft.

GEAR DRIVE

Case Sizes 1,2,3

Disassembly (Cont'd)

11. Bearing [210, 213, 226, 228 and 241] cups are mounted with interference fits and can be difficult to remove with a commercial bearing puller. Removal can be made easier by welding a 1/8" (3 mm) bead completely around the cup in the center of the roller race. Upon cooling, the cup will shrink allowing removal. Be sure to protect adjacent surfaces from weld spatter.
12. Remove bearing [210, 213] cups from the housing.
13. Remove upper bearing cap [240] and shim set [243]. Keep the shim set intact for reference at assembly.
14. Install a 1/2-13 eyebolt in the end of output shaft [247]. Lift the output shaft assembly (*Figure 2, page 5*) out of the housing.
15. Remove lower bearing cap [257] and shim set [259]. Keep the shim set intact for reference at assembly. Remove bearing [255] cup from the housing.

The gear drive is now disassembled into major subassemblies; input shaft, spiral bevel pinion cartridge, output shaft and bearing caps.

NOTE: When the gear drive is fully disassembled, all bearings, lip seals, o-rings, shims and gaskets should be replaced with new parts. When replacing bearings, always replace both cup and cone. Replace gears in sets. Spiral bevel gears must always be replaced in matched sets.

GEAR DRIVE

Case Sizes 1,2,3

Disassembly (Cont'd)

Spiral Bevel Pinion Cartridge

1. Remove the setscrew from locknut [224]. Remove the locknut and keyed lockwasher [225] from the spiral bevel pinion shaft.
2. Press spiral bevel pinion shaft [230] out of bearing [226] cone. Press bearing [228] cone off the spiral bevel pinion shaft.
3. Remove bearing [226, 228] cups from the cartridge housing.




Figure 1: Spiral Bevel Pinion Cartridge Assembly [223]

GEAR DRIVE

Case Sizes 1,2,3

Disassembly (Cont'd)

Output Shaft

1. Remove gear mounting bolts [249] and spiral bevel gear [248].
2. Remove V-ring [258] and o-ring [254].
3. Press bearing [255] cone off output shaft [247].
4. To remove bearing [241] cone, it will be necessary to cut the bearing cage and remove the rollers. Hang the low speed shaft from the tapered end so the shaft is free to turn. Apply heat (acetylene torch) while turning the shaft at approximately 30 rpm or greater. When the bearing is hot enough it will start to drop off the end of the shaft. Use a screwdriver or similar tool to push the bearing off the shaft if it hangs up.

CAUTION! Heat the bearing race only. Use a small flame to avoid damage to the shaft.




Figure 2: Output Shaft Assembly [246]

GEAR DRIVE

Case Sizes 1,2,3

Disassembly (Cont'd)

Upper Bearing Cap

1. Remove bearing [241] cup from upper bearing cap [240].




Figure 3: Upper Bearing Cap Assembly [239]

GEAR DRIVE

Case Sizes 1,2,3

Disassembly (Cont'd)

Input Shaft

1. Press bearing [213] cone off input shaft [212].




Figure 4: Input Shaft Assembly [211]

GEAR DRIVE

Case Sizes 1,2,3

Disassembly (Cont'd)**Input Shaft Bearing Cap**

1. Remove gasket [205] from cap cover [202] and bearing cap [203].




Figure 5: Input Shaft Bearing Cap

The gear drive is now fully disassembled. Clean all parts and inspect for wear. Replace worn parts as required.

GEAR DRIVE

Case Sizes 1,2,3

Assembly

Inspect all bolts and setscrews for damage after cleaning (threads, shank and head). If replacement is required, replace with the equivalent type and strength grade.

Inspect and clean all tapped holes. If threads are damaged, chase with an appropriate tap.

NOTE: The following assembly procedures require the use of a torque wrench. The values listed in Table 1, page 10 are proper tightening torques as a function of thread size.

All bearing cones are mounted with interference fits. Heat the cones and press onto the shaft. Heat bearings in oven or oil bath.

NOTE: Do not heat parts in excess of 275°F (135°C). Do not apply direct flame. Do not allow parts to touch the bottom or sides of the oven or oil bath.

Bearing [210, 213, 226, 228 and 241] cups are mounted with interference fits. Press bearing cups into their housings cold. *Placing the cups in dry ice will cause them to shrink and ease installation.*

Install V-rings with the seal lip away from the bearing. Coat the seal lip with bearing grease prior to installing the bearing cap or cover.

GEAR DRIVE
Case Sizes 1,2,3

TABLE 1: BOLT TIGHTENING TORQUE^{(1),(2)}

Bolt Size	CARBON STEEL ⁽³⁾			
	Grade 2		Grade 5	
	ft lb	Nm	ft lb	Nm
8-32	1.2	1.6	1.9	2.5
10-24	1.7	2.3	2.7	3.6
10-32	1.9	2.6	3.1	4.1
1/4-20	4.1	5.6	6	8.1
5/16-18	8.3	11	13	17
5/16-24	-	-	14	19
3/8-16	15	20	23	31
3/8-24	-	-	26	36
1/2-13	38	51	56	76
1/2-20	-	-	68	92
5/8-11	68	92	113	153
5/8-18	-	-	135	161
3/4-10	120	163	200	271
3/4-16	-	-	225	305
7/8-9	105	143	296	401
1-8	165	224	443	601
1! 1/8-7	225	305	596	808
1! 1/4-7	315	428	840	1139
1! 3/8-6	417	566	1103	1495
1! 1/2-6	555	752	1463	1983

⁽¹⁾ Tighten all fasteners to values shown in the table unless specifically instructed to do otherwise.

⁽²⁾ Lubricate all fasteners at assembly with grease, oil or an anti-seize material. Bolt threads and contact surfaces of bolt heads and nuts should be lubricated.

⁽³⁾ If fasteners cannot be lubricated, multiply table values by 1.33.

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

Most gear drive bolt patterns are circular with four, six or eight hole spacings. Install all bolts finger tight, then tighten in sequential order (see below) to 50% of the prescribed torque values. Repeat the sequence, tightening the bolts to full torque values.




Figure 6: Sequential Tightening

When tightening two or more setscrews which retain a collar, flange, or sleeve to a shaft, tighten alternately, working back and forth or around the shaft. Tighten in several steps to full torque values.

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

Input Shaft

1. Heat bearing [213] cone and press onto the spline end of input shaft [212].
2. Assemble change pinion [215], change pinion washer [216], and pinion locknut [217]. Tighten the pinion locknut to retain the bearing cone. The bearing cone must be firmly seated against the shaft shoulder. Check with a feeler gage.

NOTE: Counter-bored side of the change pinion goes against the bearing face.




Figure 7: Input Shaft Assembly [211]

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

Upper Bearing Cap

1. Press bearing [241] cup into upper bearing cap [240].
2. The bearing cup must be firmly seated against the cap shoulder. Check with a feeler gage.




Figure 8: Upper Bearing Cap Assembly [239]

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

Output Shaft

1. Heat bearing [241, 255] cones and press onto output shaft [247]. The bearing cones must be firmly seated against the shaft shoulders. Check with a feeler gage.
2. Install spiral bevel gear [248].
3. Install bolts and lockwashers [249, 250] and torque to the value shown in *Table 1, page 10*.
4. Install V-ring [258] and o-ring [254].




Figure 9: Output Shaft Assembly [246]

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

Spiral Bevel Pinion Cartridge

1. Press bearing [226, 228] cups into cartridge housing [227]. The bearing cups must be firmly seated against the housing shoulders. Check with a feeler gage.
2. Heat and press bearing [228] cone onto spiral bevel pinion shaft [230]. Allow the bearing to cool. The bearing cone must be firmly seated against the shaft shoulder. Check with a feeler gage.
3. Insert the spiral bevel pinion shaft into the cartridge housing.
4. Heat bearing [226] cone and press it onto the spiral bevel pinion shaft while turning the cartridge housing by hand. The cartridge housing should show slight resistance to turning. Maintain this pressure while the bearing cone cools.




Figure 10: Spiral Bevel Pinion Cartridge Assembly [223]

GEAR DRIVE
Case Sizes 1,2,3

Assembly (Cont'd)

5. Clamp the housing flange of the cartridge assembly in a soft jawed bench vise.
6. Spray the bearings and shaft threads with light machine oil and install locknut and keyed lockwasher [224, 225] finger tight.
7. Install bolt [218] and tighten securely.




Figure 11: Torque Reading

8. Apply a torque wrench and measure the shaft turning torque. The torque reading is to be taken while rotating the pinion shaft at about 3 rpm. Increase turning torque by tightening locknut [224]. Turn shaft one complete revolution between adjustments. Adjust to:

Case Size 1: 3.0 in lb (.34 Nm)

Case Size 2: 4.5 in lb (.51 Nm)

Case Size 3: 6.5 in lb (.73 Nm)

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

- Engage keyed lockwasher [225] and torque locknut [224] setscrew to the value shown in *Table 1, page 10*. Precision measure and record the assembled height "A" of the spiral bevel pinion cartridge assembly. This measurement will be required to set the mounting distance of the spiral bevel pinion. Delete the original dimension stamped on the cartridge housing.




Figure 12: Cartridge Measurement

GEAR DRIVE
Case Sizes 1,2,3

Assembly (Cont'd)

Gear Drive

1. Calculate required pinion cartridge shim set [236] thickness as follows:




Figure 13: Shim Calculation

$$A + MD - B = \text{Shim set [236] thickness}$$

MD = Pinion mounting distance (MD X.XXX) etched on the small end of the pinion.

B = Dimensional value marked on the housing.

A = Assembled cartridge height measurement (Figure 12, page 17.)

2. Using a paint stick, highlight the top edge of the tooth marked with an "X" on the spiral bevel pinion.
3. Install spiral bevel pinion cartridge assembly [223] and shim set [236] into the housing.
4. Install bolts and lockwashers [237, 238] and torque to the value shown in Table 1, page 10.

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

5. Measure with a micrometer the thickness of original shim set [259] for the lower bearing cap and duplicate the thickness with new shims.

Example:

If the thickness of the old shim set was .062", use (12) blue shims and (1) red shim to equal .062" when compressed.

Red = .002" (.051 mm) thick

Blue = .005" (.127 mm) thick

6. Install bearing [255] cup, lower bearing cap [257] and new shim set [259] into housing [262]. Install bolts and lockwashers [260, 261]. Torque to the value shown in *Table 1, page 10*.
7. Position the housing so that the lower bearing cap is down. Rotate the spiral bevel pinion shaft until the tooth marked "X" is on top center.
8. Using a paint stick, highlight the "X" match marks on the outside of spiral bevel gear [248].
9. Spray bearings [241, 255] with light machine oil and lower output shaft assembly [246] into the housing. *CAUTION: Make sure the spiral bevel gear teeth marked "X" straddle the pinion shaft tooth marked "X"*.
10. Install upper bearing cap assembly [239]. Bolt in place using three equally spaced bolts [244]. Alternately tighten bolts until the upper bearing cap assembly is seated on the bearing. *Do not torque the bolts; snug-up only.*

GEAR DRIVE
Case Sizes 1,2,3




Figure 14: Backlash Setting

TAB
LE 2: BACKLASH SETTING

Case Size	A	B	C	D
1	1/2" (12.7 mm)	5/16-18	1/2" (12.7 mm)	1/4" (6.4 mm)
2	9/16" (14.3 mm)	3/8-16	3/4" (19 mm)	1/4" (6.4 mm)
3	3/4" (19 mm)	3/8-16	3/4" (19 mm)	1/4" (6.4 mm)

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

11. Install a backlash tool (supplied by others) (*Figure 14, page 20*) in the spiral bevel pinion shaft and measure the backlash by placing a dial indicator against the backlash tool at a right angle to the rotation. Restrain the output shaft from turning and rotate the spiral bevel pinion shaft back and forth to measure the free movement.

The Backlash Setting (Full Indicator Movement) is etched on the spiral bevel gear.

12. Take five consecutive backlash readings. Rotate the spiral bevel pinion shaft one revolution counterclockwise after each reading. Turn the pinion shaft back to the position of the lowest backlash reading.
13. Add shims [259] to lower bearing cap [257] to decrease backlash; remove shims to increase backlash.

NOTE: Before each shim adjustment, the bolts on the upper bearing cap should be loosened. After changing the shims, the bolts on the lower bearing cap should be torqued to the value shown in Table 1, page 10 and then the bolts on the upper bearing cap should be snugged-up.

14. Measure the gap between upper bearing cap [240] and the housing. Count out new shims equal to the gap plus .003" to .004" to provide a bearing setting of .003" to .004" (.076 mm to .102 mm) endplay.
15. Install upper bearing cap assembly [239] with new shim set [243]. Install bolts and lockwashers [244, 245] and torque to the value shown in *Table 1*.
16. Check the output shaft endplay. If adjustment is required, add or subtract from shim set [243] to obtain .003" to .004" (.076 mm to .102 mm) endplay.
17. Press bearing [210, 213] cups into the housing. The bearing cups must be firmly seated against the housing shoulders. Check with a feeler gage.
18. Install input shaft assembly [211] into the housing through the change gear end.

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

19. Heat bearing [210] cone and press onto the input shaft.
20. Spray locknut [208] threads and face, and bearings [210, 213] with light machine oil. Install and tighten the locknut against the bearing cone face.

NOTE: This locknut is a special design. The locknut incorporates three threaded brass inserts, which when forced down onto the shaft by three setscrews, locks the nut to the shaft.

21. Apply torque wrench to pinion locknut [217] and measure the turning torque while rotating the input shaft at approximately 3 rpm.
22. Increase turning torque by tightening locknut [208]. To decrease torque, loosen the locknut and drive the input shaft axially (using a rawhide mallet). Turn the input shaft one complete revolution between adjustments. Adjust to:

Case Size 1: 1.5 in lb (.17 Nm)

Case Size 2: 3.0 in lb (.34 Nm)

Case Size 3: 4.0 in lb (.45 Nm)

23. Torque the locknut setscrews to the value shown in *Table 1, page 10*.
24. Remove the protective covering from a new gasket [205] and align with the notch in the cap. Apply adhesive side to the reducer side of input shaft bearing cap [203].
25. Remove the protective covering from a new gasket [205] and align with the four holes in input cap cover [202] and apply to the cover.
26. Place the input shaft bearing cap/gasket against the housing. Orient the notch at the 12 o'clock position.
27. Slide V-ring [204] onto the input shaft just past the end of the keyway. The V-ring lip is to face away from the bearing.
28. Place the cap cover/gasket over the end of the input shaft with gasket side facing the input shaft bearing cap.

GEAR DRIVE

Case Sizes 1,2,3

Assembly (Cont'd)

29. Using the cap cover, push the V-ring down the shaft. Assemble the cap cover and the bearing cap to the housing with bolts and lockwashers [206, 207]. Torque the bolts to the value shown in *Table 1, page 10*.
30. Remove pinion locknut [217], change pinion washer [216] and change pinion [215].
31. Slide change gear [221] (taper bore) into place on spiral bevel pinion shaft [230]. The change gear bore and spiral bevel pinion shaft taper must be clean and dry prior to assembly.
32. Install key, bolt, lockwasher and change gear washer [222, 218, 219 and 220]. Torque the bolt to the value shown in *Table 1*.
33. If the gear drive is equipped with a low speed oil wiper, install slinger trough [332]. See the *Supplemental Information* section of this manual.
34. Reinstall the change pinion, change pinion washer and pinion locknut. *NOTE: Counter-bored side of the change pinion goes against the bearing face.* Torque the locknut to the value shown below:

Case Sizes 1&2	: 30 ft lb (41 Nm)
Case Size 3	: 58 ft lb (.79 Nm)
35. Remove the protective covering from a new gasket [277], align holes and apply to change gear cover [276].
36. Install the change gear cover with bolts and lockwashers [278, 279]. Torque the bolts to the value shown in *Table 1*.
37. Rotate the input shaft by hand until the output shaft makes at least one turn. Check for any binding.
38. Add grease to bearings [241, 255] and fill the gear housing with oil. See *Agitator IOM Manual, Lubrication, Gear Drive*.
39. Reinstall gear drive coupling half [351]. See *Agitator IOM Manual, Installation, Rigid Shaft Coupling*.
40. Reinstall motor bracket [131] and motor [100]. See *Agitator IOM Manual, Installation*.




Figure 15: HT Gear Drive: Sizes 1,2,3

GEAR DRIVE ITEM LIST

Case Sizes 1,2,3

Item #	Description	Qty.	Item #	Description	Qty.	Item #	Description	Qty.
200	gear drive assembly	1	223	spiral bevel pinion cartridge assembly	1	246	output shaft assembly	1
202	cap cover	1	224-001	locknut with setscrew	1	247	output shaft	1
203	bearing cap	1	225	keyed lockwasher	1	248-001	spiral bevel gear	1
204-001	V-ring	1	226	bearing	1	249	bolt	
205	gasket	2	227	cartridge housing	1	250	lockwasher	
206	bolt	4	228	bearing	1	254	o-ring	1
207	lockwasher	4	230	spiral bevel pinion shaft	1	255	bearing	1
			236	shim set	1	257	lower bearing cap	1
208-001	shoe locknut with setscrews	1	237	bolt	6	258-001	V-ring	1
210-001	bearing	1	238	lockwasher	6	259	shim set	1
			239	upper bearing cap assembly	1	260	bolt	
211	input shaft assembly	1	240	upper bearing cap	1	261	lockwasher	
212	input shaft	1	241	bearing	1	262	housing	1
213-001	bearing	1	243	shim set	1	276	change gear cover	1
			244	bolt		277	gasket	1
215	change pinion	1	245	lockwasher		278	bolt	
216	change pinion washer	1				279	lockwasher	
217-001	pinion locknut	1				280-001	breather	1
218	bolt	1				282	hex bushing	1
219	lockwasher	1				283	pipe plug, NPT	1
220	change gear washer	1				284	magnetic drain plug, NPT	1
221	change gear	1				285	oil level sight glass	1
222	key	1				286	pipe plug, NPT	1
						288	grease fitting	2
						289	relief fitting	1
						290	elbow fitting	1



© Chemineer, Inc. 2003