Tips for new LAS Regulations

The AER may now refuse LAS files for:

- Date
- Service Company
- Start
- Stop
- Step
- Mnemonic spacing


Editing a LAS file is as simple and opening it in Notepad.

Date

Should now be the date the well TD'd.

Service Company

The company providing the LAS file.



Start, Stop, Step

These 3 fields must now be lines 7, 8, and 9. To do this add a bank line before Date, highlight STRT, STOP, STEP and right click Cut. Then right click paste into the blank line above Date. Delete the empty space between LIC and NULL.

STOP depth also must not exceed TD by more the 5m. By default GEOstrip will export an LAS to the end of the logs Depth range. To correct this simply type the TD depth in the LAS export dialog.

Mnemonic Spacing

The AER no longer accepts LAS files with spaces in mnemonic names. There is a separate link on the GRS downloads page to address this.

